



Remote Control

1. Away Arm Button
2. Disarm Button
3. Panic Button
4. Home Arm button
5. LED Indicator
6. Back Cover

Afstandsbediening

(Nederlands)

1. Buitenshuis inschakelen
2. Uitschakelen
3. Noodknop
4. Binnenshuis inschakelen
5. LED indicator
6. Afdekplaatje batterij (achterzijde)

ENGLISH

Getting Started

1. Slide open the back cover, insert the battery provided and close the back cover.
2. If the accessory is purchased separately from the kit, follow instruction below to include the accessory into your control panel
If the accessory is already included in your alarm system, skip step 3-5.
3. Put the Control Panel into learning mode.
4. Press any of the buttons to learn the Remote Control.
5. Refer to Control Panel manual to complete learning process.

Operation

- Press the **Away Arm** button to away arm your alarm system.
- Press the **Home Arm** button to home arm your alarm system.
- Press the **Disarm** button to disarm your alarm system.
- Press and hold the **Panic** button for 3 seconds to activate a Panic alarm regardless of system mode.
- The LED will light up whenever any button is pressed.

Battery

The Remote Control uses one **CR2032 3V** lithium battery. It features low battery detection function to notify the Control Panel when battery voltage is low.

When the Remote Control is on low battery, follow the procedure below to change the batteries.

1. Slide open the back cover
2. Remove the old battery
3. Insert the new batteries observing correct polarity
4. Replace the back cover.

Specification

Environmental Condition:

-10°C to 40°C, relative humidity 85% non-condensing.

Radio:

868 MHz

NEDERLANDS

Aan de slag

1. Schuif het afdekplaatje aan de achterzijde open, plaats de bijgeleverde batterij en schuif het afdekplaatje weer dicht.
2. Indien dit accessoire los van de rest van de set aangeschaft is, dient u de onderstaande stappen uit te voeren om accessoire en controlepaneel te koppelen.
Indien dit accessoire samen met de rest van uw systeem is geleverd, kunt u stap 3 – 5 overslaan.
3. Schakel de “koppelmodus” van uw controlepaneel in.
4. Druk op een willekeurige knop op de afstandsbediening om deze met controlepaneel te verbinden.
5. Zie verder de handleiding van het controlepaneel voor afronding van het koppelproces.

Bediening

- Druk de Buitenshuis inschakelen knop in om het systeem in te schakelen als u de woning verlaat.
- Druk de Binnenshuis inschakelen knop in om het systeem in te schakelen als u in huis blijft.
- Druk de uitschakelen knop in om het systeem uit te schakelen.
- Druk de Noodknop gedurende 3 seconden in om een noodalarm te activeren, ongeacht de modus waarin het systeem zich bevindt.
- De LED indicator licht op wanneer een knop wordt ingedrukt.

Batterij

De afstandsbediening gebruikt 1 CR2032 3V lithium batterij. Bij lage batterijspanning wordt er een melding weergegeven op het controlepaneel.

Om de batterij te vervangen volgt u de volgende stappen:

1. Schuif het afdekplaatje aan de achterzijde open.
2. Verwijder de lege batterij
3. Plaats de nieuwe batterij op de juiste wijze (let hierbij op de polariteit)
4. Schuif het afdekplaatje weer dicht.

Technische Specificaties

Omgevingscondities

-10° C tot 40° C, relatieve luchtvochtigheid 85%, niet condenserend.

Radiofrequentie

868 MHz