



**Instructions for software installation**

**ENDEAVOUR 1000HD**

**incl. office software**

**English**

---

## Installation

Dear user,


to the latest update for your device to download please carefully follow the instructions that are described here.



**ATTENTION!** This software update will reset the device **to factory settings**. Be sure to **save your personal data** (videos, pictures, music, etc.) on an SD card, or your PC before you begin. Your apps (free and fee-based) can you download again free after the upgrade by logging on again with the original Google account, in the Google Play Store.



To perform this upgrade you need to use a standard **micro SD card** with at least 500 MB free space. It may remain other files on the card. This will not be deleted or changed.



1. First Download the file Endeavour 1000HD\_V20130805.zip and unzip the file.
2. Copy the 5 files in the root directory of the SD card.



aml\_autoscript




factory\_update\_param



u-boot



uImage\_recovery



update

- aml\_autoscript
- factory\_update\_param.aml
- u-boot.bin
- uImage\_recovery
- update.zip

- 
3. Make sure that the device is still **at least 50% battery remaining capacity** and has **completely shut off. Not** only in **standby** mode!

### Step by step update

1. Insert the SD card into the device.
2. Press **Volume -** key and hold it down. Then press additionally the **off switching button** until the Blaupunkt logo appears.
3. When the display shows the Blaupunkt logo, leave the **Off switching button**, but hold down the **volume -** yet pressed for a further 3 seconds. Then you can also release.
4. In this way you begin the upgrade. This is shown by the Android robot and generates an automatic restart when the upgrade is complete.

**Remark:** If the device switch while the update to stand-by mode (black screen), please follow the following steps:

5. Please press the power button for 1-2 seconds, after which the display will be somewhat brighter, and after about 30-40 seconds the display will begin the update (Android robot).
6. After the upgrade, the unit will start automatically by itself.

**Remark:** The display of the black screen (standby) while the update takes place, because of the new driver installation. Please take a little patience during the upgrade process, and please don't plug out the SD card before the automatic restart of the device.



**IMPORTANT NOTE:**

**Please do not interrupt in any case the update process until the tablet is rebooted! The file system may be damaged and fail to start. This damage is not covered by the warranty and requires a paid repair.**