

**● BLAUPUNKT**

**Instruction Manual**



*Enjoy it.*

**EM-10**

WIRED EARPHONE

## TECHNOLOGY SPECIFICATION

Speaker size : 10mm

Sensitivity : 108±3dB

Impedance : 16 Ω

Frequency response : 20 ~ 20000Hz

Cable length : 120cm

Plug Pin : 3.5mm

## PRODUCT DESCRIPTION


Standard 3.5mm plug pin, EM-10 can use in most of portable broadcast equipments, such as smart cellphone, ipad, laptop, MP3 or professional audio player, etc. Provide you several models backup earcap help you select the most comfortable way to listen music. ABS plastic ear conch and the lightweight appearance make it comfortable to wear ! The design of wire control turning makes no influence for listen to music and phoning. The slipping and locking cable design can bring a enjoyable experience to you.

## CAUTION

- 1) Don't wear at a high volume for a long time. Avoid dust, moisture and stains.
- 2) Handle with care, don't contact high temperature and sharp objects to avoid damaging the structure and function of product.

## HOW TO USE

- 1) Note the difference between the right(R) and left(L) earphones and insert earphone into each ear.
- 2) **Caption:**
  1. **Pause/Play** (short press button 1 time)
  2. **Previous Music** (continuous short press button 3 times)
  3. **Next Music** (continuous short press button 2 times)
  4. **Answer Calls** (short press button 1 time)
  5. **Hang Up Calls** (short press button 1 time after answer calls)
  6. **Reject Calls** (long press button about 1 second)



Thank you for purchasing our EM-10 Wired Earphone. Please read the instruction carefully before using it, in order to know the proper operations of the product.

## **WARRANTY INFORMATION 1 YEAR\***

If you have issue with EM-10 product please contact our service center.

Authorized Service Center Blaupunkt Speakers

Address: Envent World Wide Pvt. Ltd., Khasra No- 15/15 (4-16), Village Samalkha, Tehsil Vasant Vihar, New Delhi-110037.

E-Mail: [wecare@blaupunkt-audio.in](mailto:wecare@blaupunkt-audio.in) | Tel: 1800 843 4333

Please prepare and submit the following information during the telephone or e-mail notification to facilitate the process:

- Serial number
- Date of purchase
- A copy of proof of purchase in case of warranty

**Note - Important information:**

Please use the original packaging or other suitable packaging to protect the unit in transit.